Part No.	Description	Plate No.	No. per Unit	Remarks
	NOTE: ITEMS UNDER THIS HEADING ARE SUPPLIED ONLY WHEN SPECIALLY ORDERED.			
C.5596	WINDSCREEN WASHER ASSEMBLY		1	FOR USE ONLY ON OPEN AND DROP HEAD COUPE.
C.9178	WINDSCREEN WASHER ASSEMBLY		1	FOR USE ONLY ON FIXED HEAD COUPE.
	NOTE: C.5596 or C.9178 covers the supply of a Windscreen Washing Unit complete with Mountings, Fixings and Rubber Tubes, etc.			
C.5473/I	JAR, PUMP AND BRACKET ASSEMBLY (800008)		I	
	(66666)			FOR USE ONLY ON OPEN AND
C.5473/2 C.5473/3 C.5473/8 C.5498	Jar only (Glass) (X.78369) Pump and Cover Assembly (X.82540) Bracket and Strap Assembly (X.78364-IE) Strainer Tube Assembly (X.76431-IM)		[[[DROP HEAD COUPE MODELS.
C.9179	JAR, PUMP AND BRACKET ASSEMBLY (800076)		ı	
C.9184 C.5473/3 C.9185 C.5498	Jar only (Glass) (800037) Pump and Cover Assembly (X.82540) Bracket and Strap Assembly (800075/E) Strainer Tube Assembly (X.76431-IM)		; 1 1	FOR USE ON FIXED HEAD COUPE ONLY.
	RUBBER TUBES FOR WINDSCREEN WASHER			FOR USE ONLY ON OPEN CARS.
C.5596/1	Tube, from Connection under Pump to "T" Junction		ī	
C.5596/2	(81846—19" long) Tube, from top of Pump to Dash Control (81846—43"		1	FOR L.H. DRIVE OPEN CARS ONLY
C.5596/3	long) Tube , from top of Pump to Dash Control (81846—58"	ı	1	FOR R.H. DRIVE OPEN CARS ONLY
C.5596/4 C.5472/12	long) Tube, from Dash Control to Manifold (81846—26" long) Tube, from "T" Junction to R.H. Jet (L.H. Drive cars only) and to L.H. Jet (R.H. Drive cars only)	1	!	
C.5472/13	(F.15—19" long) Tube, from "T" Junction to L.H. Jet (L.H. Drive cars only) and to R.H. Jet (R.H. drive cars only) (F.15—43" long)))	I	

Part No.	Description	Plate No.	No. per Unit	Remarks
	RUBBER TUBES FOR WINDSCREEN WASHER			FOR USE ONLY ON DROP HEAD COUPE.
C.5472/9	Tube, from Connection under Pump to "T" Junction		ı	
C.5472/10	(81846—16" long) Tube , from top of Pump to Dash Control (81846—41"		1	FOR L.H. DRIVE DROP HEAD COUPE
C.5472/14	Tube, from top of Pump to Dash Control (81846—55" long)		1	ONLY. FOR R.H. DRIVE DROP HEAD COUPE
C.5472/11 C.5472/19	Tube, from Dash Control to Manifold (81846—23" long) Tube, from "T" Junction to L.H. Jet (L.H. drive cars only) and to R.H. Jet (R.H. drive cars only)		i	ONLY.
C.5472/20	(F.15—40" long) Tube, from "T" Junction to R.H. Jet (L.H. drive cars only) and to L.H. Jet (R.H. drive cars only) (F.15—16" long)		I	
	RUBBER TUBES FOR WINDSCREEN WASHER			FOR USE ONLY ON FIXED HEAD COUPE.
C.9186	Tube, from Connection under Pump to "T" Junction			
C.9187	(81846—24" long) Tube, from top of Pump to Dash Control (81846—54"	•	I	
C.9188	long) Tube , from Dash Control to Manifold (81846—20" long)		Ţ	
C.5472/19 C.5473/13	Tube, from "T" Junction to R.H. Jet (F.15—40" long) Tube, from "T" Junction to L.H. Jet (F.15—26" long)		ł	
C.5473/6	"T" CONNECTION FOR RUBBER TUBE (X.87223/I)		I	
C.5473/4	JET ASSEMBLY, COMPLETE (X.78778—C)		2	
C.5495 C.5499	Jet only (81600-C) Button (Knurled) for Jet cleaning (81153-1C)		2 2	
C.5496 C.5497	Washer (Plastic) on Button (81635) Washer (Rubber) between Jet Assembly and Scuttle (75172)		2 2	
C.5472/7	CONTROL BUTTON ASSEMBLY ON INSTRUMENT PANEL (900306)		1	

Part No.	Description	Plate No.	No. per Unit	Remarks
C.5473/5	CONNECTION, IN INLET MANIFOLD, FOR TUBE TO CONTROL BUTTON (770750)		ı	Fitted from Chassis No. : 800001 to 800060. 810001 to 811697. 804001 to 804425. 814001 to 814853. 807001 to 807287. 817001 to 817895.
C.11490	CONNECTION, IN INLET MANIFOLD, FOR TUBE TO CONTROL BUTTON (770793)		ı	Fitted to Chassis No. 800061 and subs. 811698 and subs. 804426 and subs. 814854 and subs. 807288 and subs. 817896 and subs.
C.11491	CHECK VALVE, IN RUBBER TUBE, BETWEEN MANIFOLD CONNEC- TION AND CONTROL BUTTON (900292)		ı	Fitted to Chassis No. 800061 and subs. 811698 and subs. 804426 and subs. 814854 and subs. 807288 and subs. 817896 and subs.
BD.8106	BRACKET, ON SCUTTLE, MOUNTING JAR BRACKET		1	
NS.119/4D NS.119/10D BD.8107 NN.119/L C.723/A	Screw, Set, securing Scuttle Bracket Screw, Set, securing Jar Bracket Distance Piece, on Setscrew, holding Jar Bracket Nut, on Setscrews Washer, Shakeproof, under Nuts		4 ! ! 5 5	FOR USE ONLY ON OPEN AND DROP HEAD COUPE MODELS.
UFS.119/4R UFN.119/L C.723/A	Screw, Set, securing Jar Nut, on Setscrews Washer, Shakeproof, under Nuts		3 3 3	FOR USE ONLY ON FIXED HEAD MODELS.
C.6838	WIRE SPOKE ROAD WHEEL (CHROMIUM PLATED)		5	
C.9142 C.11785 C.9144	Spoke (long) at front of Wheels Spoke (short) at rear of Wheels Nipple for Spokes		90 180 270	

Part No.	Description	Plate No.	No. per Unit	Remarks
C.6649	TYRE (DUNLOP RACING $6.00'' imes 16'')$		5	
C.6650	INNER TUBE (DUNLOP RACING $6.00'' imes 16''$)		5	
C.10156	TYRE (DUNLOP WHITE WALL)		5	
C.8385	RIMBELLISHER		4	
C.11819	TOOL FOR REMOVAL OF HUB DISCS		ı	
C.11550	EXTERNAL LUGGAGE RACK FOR INSTALLATION TO LUGGAGE COMPARTMENT LID		1 .	
C.82 9 5	FOG LAMP (LUCAS 55128/B—SFT.576)		2	FOR ALL COUNTRIES EXCEPT FRANCE.
C.8295/I C.8295/2 C.8295/3	Light Unit (Lucas 554813) Adaptor (Lucas 554667) Clamp, securing Light Unit to Fog Lamp Shell		2 2 2	
C.8295/4 C.8295/5 C.8295/6	(Lucas 535009) Screw, securing Clamp (Lucas 534379) Base for Fog Lamp Seating (Lucas 534386) Nut, securing Fog Lamp to Mounting Bracket		2 2 2	
323	(Lucas 180377) Bulb, 48 watt		2	
C.9615	FOG LAMP (LUCAS 55133/B—SFT.576)		2	FOR EXPORT TO FRANCE.
C.9615/1 323	Light Unit (Lucas 554820) Bulb, Amber Lens, 48 watt		2 2	
	All other items for Fog Lamp C.9615 are identical with Fog Lamp C.8295.		-	

Part No.	Description	Plate No.	No. per Unit	Remarks
BD.9242	BRACKET FOR MOUNTING OF L.H. FOG LAMP		i	
BD.9243	BRACKET, FOR MOUNTING OF R.H. FOG LAMP		1	
C.8297 BD.9240 BD.9241 BD.10416	Grommet, in Plinth Panels, for Fog Lamp Mounting Distance Collar through Grommets Nut, securing Fog Lamps to Brackets Packing Plate for Fog Lamp Mounting		2 2 2 2 2	
C.9117	SWITCH OPERATING FOG LAMPS		i	Replaces Standard Lamp Switch on Instru- ment Panel.
C.9118	(LUCAS 31524/A) Escutcheon for Switch (Lucas 305604)		!	ment ranei.
C.9119 C.9121 C.8841 C.5204	Cable for Fog Lamp Switch (Lucas 862435/A) Connector for L.H. Fog Lamp (Lucas 862437/A) Cable for Fog Lamp (Lucas 862334) Earth Terminal (Lucas 860019)		! ! 2 !	